

PRO X PRIME

Guidelines for Finishing PRO X PRIME

When finishing, the manufacturer recommends using a good quality 100% acrylic latex topcoat. If you are finishing the smooth side of the product, it is also recommended that you scuff sand the entire surface using 150 grit sandpaper prior to painting. After sanding, make sure to wipe off any dust before applying the finish coat of 100% acrylic latex topcoat. If you choose not to sand the primer prior to painting, we recommend that you try a small test sample of your paint on the primed surface to test for adhesion to the primer. The test spot

should be left to cure for up to seven days to reach full adhesion. If you feel that the adhesion is not sufficient, you will need to scuff sand the surface as stated prior. Because of the wide variety of paint available on the market and the many different application techniques, we cannot be held responsible for adhesion issues related to the quality of the paint or the preparation of the primer prior to painting. Please refer to the paint manufacturer's instructions for further details on the application of your chosen paint.

northcentral.cedarcreek.com